



Veratox for Casein Allergen Procedure

Note: Please read kit instructions completely before performing test.


Questions? Call 800/234-5333 or 517/372-9200.



1. Add 150 μ L controls and extracted samples to transfer wells.




2. Transfer 100 μ L to the antibody wells. Incubate for 10 minutes.




3. Dump liquid from antibody wells.



4. Wash wells thoroughly 5 times with washing buffer solution.




5. Tap out water on absorbent paper towel.




6. Transfer 100 μ L conjugate from reagent boat to antibody wells using 12-channel pipettor. Incubate for 10 minutes.




7. Repeat steps 3-5 by dumping out the liquid, thoroughly washing the wells and tapping dry.



8. Transfer 100 μ L substrate from reagent boat to antibody wells using 12-channel pipettor. Incubate for 10 minutes.



9. Transfer 100 μ L Red Stop from reagent boat to antibody wells.



10. Read results in a microwell reader with a 650 nm filter.

Product Specifications

Range of quantitation:

2.5 - 15 ppm

Controls provided:

0, 2.5, 5, 10 and 15 ppm

Testing time:

Less than 1 hour



620 Leshar Place • Lansing, MI 48912
800/234-5333 (USA and Canada only) • 517/372-9200 • fax: 517/372-2006
e-mail: foodsafety@neogen.com • www.neogen.com